

# Hose Reel OPERATION MANUAL

Part No.: AE2017



### NINGBO HIJET CLEANING EQUIPMENT CO., LTD

Add: No.618 Dongming Road, Zhenhai Economic Development Zone, Ningbo, CHINA 315221 Tel: 86-574-26289620 Fax: 86-574-26251988 E-mail: info@hijet.com.cn

> SERVICE CENTER: ROYAL PALM BEACH FL 33421 Tel: (561)249-2830 Fax: (561)249-2871

WOJET AE2017 WOJET AE2017

### **Hose Reel AE2017**


### **Specifications:**

Capacity: 50feet of 3/8"hose(AE2017)

Inlet: 3/8"MNPT Outlet: 3/8"FNPT

Maximum Pressure: 4000PSI / 275Bar

Maximum Temperature: 150°C / 302°F



# **Safety Precautions**

- Make sure incoming pressure does not exceed the rated pressure.
- Use the proper eye protection when assembling and using the hose reel.
- 3.Assemble the hose reel on a clean workbench free of debris and water.
- 4.Use soap and water when checking for air leaking.
- 5. Keep children away from the work area.

Warning: Exposure of skin directly to pressurized air or

fluids could result in severe body injury.

## **Installation and Assembly**

Noted: You will need to prepare appropriate hardware for mounting your new hose reel. Holes have been provided in the reel base, for mounting on a suitable flat surface. You will also need to prepare hose for the reel. Refer to specification information to determine the correct hose length.



Spring Locking Clip



3/8" FNPT Outlet



**High Pressure Swivel** 



Anti Rewind Block